

# Photovoltaic DC busbar remote box





## Overview

---

Are PV DC combiner boxes CE-compliant?

The PV DC COMBINER BOX is CE-compliant in accordance with Directive 2014/35/EU (Low Voltage Directive) and with Directive 2014/30/EU (EMC Directive). PV DC COMBINER BOX is a complete range of tailor-made Level 1 combiner boxes for utility-scale photovoltaic systems.

How does the PV DC combiner box with monitoring work?

By default, the PV DC COMBINER BOX with monitoring comes with the internal communications pre-wired. This means that there is a communication cable between the device and 3 terminals at the bottom side of the enclosure.

How do I connect a DC combiner box to a solar inverter?

The output cables must be connected to a Level 2 combiner box, which will join DC+ and DC- from other Level 1 combiner boxes, or directly to the solar inverter. The enclosure of the PV DC COMBINER BOX is made of Glass Fibre Reinforced Polyester (GFRP). The enclosure provides IP65 and IK07 or higher in accordance with IEC 62208.

What fuses are included in a PV DC combiner box?

The PV DC COMBINER BOX is provided with gPV fuses in accordance with IEC 60269-6:2010. Each design of combiner box contains the most suitable fuse rating specially selected for each project, depending on  $I_{sc}$  of PV strings, on voltage rating and on ambient temperatures.

How many inputs & outputs does a PV DC combiner box have?

The PV DC COMBINER BOX product range offers solutions from 8 to 32 inputs and 1 or 2 outputs. These can be designed for systems with string voltage of 1000 or 1500 V DC. The necessary string cables (+ and -) are to be connected at the inputs whereas one or two DC+ and DC- main cables will be at the output side.



Does the PV combiner box have a DC disconnection switch?

The PV DC COMBINER BOX has a DC disconnection switch by default. The DC voltage of the switch depends on the voltage of the PV string. The switch disconnecting making and breaking capacity (according to the IEC 60947-3) has been selected to assure that it can switch the circuit at full load at the maximum operating temperature.



## Photovoltaic DC busbar remote box

---

## Contact Us

---

For catalog requests, pricing, or partnerships, please visit:  
<https://www.legnano.eu>